UC SANTA BARBARA Environmental Health & Safety Design, Facilities & Safety Services		Procedure No.: SS-MHA-RADARM-S	
		Authorized/Approved By: John M. Seaman, EHS Industrial Safety Manager	
Issue Date: 05/07/2013	Review Date: 10/05/2021	Page Number: 1 of 4	

1. Hazard Management Details - General		
Shop/Equipment Item: RADIAL ARM SAW	Make/Model No.:	Serial No.:
Department:	Work Location:	
Person(s) Conducting Hazard Analysis: JOHN M. SEA EHS Industry	AMAN ial Safety Manager	Date Conducted: May 5, 2013
Equipment Photo:	Description of Use:	Summary of Key Risks: (refer to appropriate subsections)
	A radial arm saw is a specialized piece of woodworking equipment used to: • Cross cut boards to length. • Square edges. • Cut housings, miters and bevels cuts. The saw arm can be raised or lowered to adjust the depth and swung from side to side to adjust the side horizontal angle of the cut.	 Entanglement Inhalation Eye Injury Trauma (Impact and Cutting) Hand and/or Foot Injury Noise Fire Electrical Shock

UC SANTA BARBARA Environmental Health & Safety Design, Facilities & Safety Services		Procedure No.: SS-MHA-RADARM-S
		Equipment/Machine: RADIAL ARM SAW
Title: Shop Equipment Hazard A	nalysis & Management Form	
Issue Date: 05/07/2013	Review Date: 10/05/2021	Page Number: 2 of 4

2. Documentation:				
Relevant Legislation/Standards	Y / N	Comments:		
a. Is equipment required to be registered?	Y N			
b. Is a user license/Certification required?	Y N			
c. Key Reference Materials Required:	AS4024 Safegua	AS 1473 Guarding and safe use of woodworking machinery AS4024 Safeguarding of machinery AS/NZS 3760 In service safety inspection and testing of electrical equipment		
Equipment Documentation	Y / N	Comments:		
a. Are operator's manuals accessible?	Y 📉 N			
b. Is this a restricted use item?	Y 📉 N			
c. Does this equipment require safe use document(s)/test?	Y 📉 N 🗌			

	3. Personal Protective Equipment (PPE) Required (Check the box for required PPE)						
Gloves	Face Masks	Eye Protection	Face Shield	Hearing	Safety Footwear	Protective	Welding
				Protection			Mask
			OPTIONAL				

UC SANTA BARBARA Environmental Health & Safety Design, Facilities & Safety Services		Procedure No.: SS-MHA-RADARM-S
		Equipment/Machine: : RADIAL ARM SAW
Title: Shop Equipment Hazard	Analysis & Management Form	
Issue Date: 05/07/2013	Review Date: 10/05/2021	Page Number: 3 of 4

4. Hazard Analysis			
TASK	HAZARD	CAUSE	PREVENTIVE MEASURE
a. Routine Operation	Entanglement	Long hair, loose clothing, rags, cleaning brushes and jewelry could become entangled in the moving parts of the saw.	Use aprons to restrict loose clothing. Use hair ties/nets to secure long hair. Do not wear jewelry or loose accessories when operating machine.
	Inhalation	Dust/particles generated during machine operation	Appropriate natural ventilation, use of disposable respirators
	Eye Injury	Projectiles, dust/particles, sparks	
	Trauma	The exposed moving saw blade presents a significant risk to an operator's hands and body parts.	Safety glasses w/side shield, goggles, face shield Situational awareness, make sure operator hands and body parts are kept clear of moving saw blade
	Foot Injury	Drop object on foot	during operation and maintenance; machine guards
	Hand Injury	Point of operation, ingoing nip points, rotating parts, flying chips/sparks	Wear safety shoes/boots Machine guards, situational awareness
	Noise	Operation of machine, cutting materials	Wear appropriate hearing protection
	Fire	Sparks	Remove all combustibles and fire hazards from work area, have fire extinguisher nearby
	Electrical Shock	Improper grounding, set-up, operation, or maintenance, damaged electrical cords	Proper grounding of frame, manufacturer's instructions strictly followed, inspect cords
b. Routine Maintenance or Repair	Trauma	Uncontrolled/unexpected start up of machine	Make sure equipment is serviced on a regular basis, tested & tagged .Use appropriate energy isolation procedures prior to beginning maintenance work
c. Shutdown and Isolate Unit	Electrical Shock/Laceration	Failure to follow Lockout/Tagout procedures	Strictly adhere to established Lockout/Tagout protocols

UC SANTA BARBARA Environmental Health & Safety Design, Facilities & Safety Services		Procedure No.: SS-MHA-RADARM-S
		Equipment/Machine: : RADIAL ARM SAW
Title: Shop Equipment Hazard A	alysis & Management Form	
Issue Date: 05/07/2013	Review Date: 10/05/2021	Page Number: 4 of 4

Equipment Procedures/ Requirements

- 1. Operate equipment in strict accordance with Manufacturer's instructions and in accordance with OSHA 29 CFR 1910.212 and 1910.213.
- 2. Only authorized users can operate equipment
- 3. A mechanical or electrical power control shall be provided to make it possible for the operator to cut off power without leaving his position at the point of operation.
- 4. Machines designed for a fixed location shall be securely anchored to prevent walking or moving.
- 5. One or more methods of machine guarding shall be provided to protect the operator and other employees in the area from hazards such as those created by point of operation, ingoing nip points, rotating parts, flying chips and sparks.
- 6. All portions of the saw blade shall be enclosed or guarded, except for the working portion of the blade between the bottom of the guide rolls and the table.
- 7. Report any observed defect or safety hazard to your supervisor immediately.
- 8. Where any object handled would possibly cause injury to feet if dropped, safety shoes will be worn.
- 9. Where any object handled could possibly cause cuts, punctures or abrasions to hands, appropriate gloves will be worn. (*Exception:* where rotating machinery presents a greater hazard of entangling gloves, they are optional with written justification).

10. Keep hands, hair and loose clothing clear of all moving parts.